

FACT SHEET

AUTOMATIC HEADLAMP SWITCHING

AHS-LB Automatic headlamp switching between daytime running lights and dipped beam




With automatic headlamp switching between daytime running lights and dipped beam, the dipped beam is switched on or off automatically depending on the ambient light.

Automatic headlamp switching provides increased safety in poor ambient light, such as in tunnels, at dawn and at dusk.

A sensor in the windscreen continuously monitors the ambient light, and depending on if it is good or poor the system switches between the daytime running lights and the dipped beam. The daytime running lights are on in good light conditions and in poor light conditions the dipped beam is on.

Automatic headlamp switching can be turned on or off with the light switch in the instrument panel. When the light switch is turned to position 1 or 2, automatic headlamp switching is on.



Automatic headlamp switching is on in position 1 and 2.



SAFETY

- In poor ambient light, the dipped beam is switched on automatically.



DRIVER APPEAL

- Lets the driver focus on driving, regardless of changing ambient light.

| | Ambient light | |
|-------------------------|---------------|------|
| | Good | Poor |
| Daytime running lights | On | Off |
| Dipped beam | Off | On |
| Side marker lamps | On | On |
| Rear positioning lights | On | On |