

FACT SHEET

SLEEPER CONTROL PANEL



Control panel in the sleeping area

The control panel is centrally placed on the rear wall. You can operate a range of installed functions in the truck while staying in the sleeping area.

The panel is available in two versions, Basic and Luxury.

Sales variants

SLCP-BAS Basic sleeper control panel

SLCP-LUX Luxury sleeper control panel



DRIVER APPEAL

- Convenient operation from the sleeping area.
- Easy to control most of the in-cab functions.



SAFETY

- With SLCP-LUX you can activate Surveillance mode if the Camera Monitor System is chosen for the truck.

FACT SHEET

SLEEPER CONTROL PANEL

SLCP-BAS




SLCP-BAS, basic sleeper control panel

The basic version offers control of a number of useful functions:

Interior light	On & off
Parking heater	On & off, temperature adjustment
Roof hatch	Open & close

SLCP-LUX



SLCP-LUX, luxury sleeper control panel

The luxury version enables control of almost all in-cab functions. The panel has soft keys and a small display that shows the relevant information.

The display shows the current time when it is not used, and is dimmed after a short while.

If the truck has the Camera Monitor System (CMS), the surveillance function can be activated from the panel. The following functions are included:

Interior light	Light mode and dimming
Alarm clock	On & off and timer
Parking heater	On & off, timer and temperature adjustment
Parking cooler	On & off, temperature adjustment
Roof hatch	Open & close
Door lock	Open & lock
Side door windows	Open & close
Audio	On & off, volume, source selection
CMS surveillance	On & off